





PRODUCT CONFORMITY CERTIFICATE

This is to certify that the

Signature® Flowmeter with TIENet™ 310 ultrasonic level sensor

manufactured by:

Teledyne ISCO

4700 Superior Street, Lincoln, Nebraska, 68504-1398 USA

has been assessed by Sira Certification Service and for the conditions stated on this certificate complies with:

MCERTS Performance Standards for Continuous Water Monitoring Equipment – Part 3 Version 3 dated July 2018

The combined performance characteristic (U_c , the expanded uncertainty) is **0.67%** (Class3)

Certification Ranges:

0.003 to 3 m

Project No.: 16W27658 / 80017350
Certificate No: Sira MC140261/02
Initial Certification: 04 November 2014
This Certificate issued: 17 March 2021
Renewal Date: 04 November 2024

1.5.

Andrew Young
Environmental Project Engineer

MCERTS is operated on behalf of the Environment Agency by

Sira Certification Service



Unit 6, Hawarden Industrial Park Hawarden, Deeside, CH5 3US Tel: +44 (0)1244 670 900



The MCERTS certificate consists of this document in its entirety.
For conditions of use, please consider all the information within.
This certificate may only be reproduced in its entirety and without change
To authenticate the validity of this certificate please visit www.csagroupuk.org/mcerts







Certificate Contents

Approved Site Application	2
Basis of Certification	
Product Certified	
Certified Performance	
Description	5
General Notes	

Approved Site Application

Any potential user should ensure, in consultation with the manufacturer, that the monitoring system is suitable for the intended application. For general guidance on monitoring techniques refer to the Environment Agency Monitoring Technical Guidance Notes available at www.mcerts.net

The product is suitable for use, where it is appropriate, for regulated applications such as abstraction, effluent discharge, ultraviolet disinfection and industrial processing.

The field trial took place for three months on the final effluent weir of a food processing plant.

Basis of Certification

This certification is based on the following Test Report(s) and on Sira's assessment and ongoing surveillance of the product and the manufacturing process:

- R1 WRc Report Number UC9578 v03 dated July 2013
- R2 WRc Report Number UC9663 v03 dated July 2013
- R3 Signature Flow Meter Field Test Report 20131022 dated 21 October 2013
- R4 WRc Report Number UC10265 dated August 2014

Product Certified

The Signature® Flowmeter with TIENet™ 310 ultrasonic level sensor system consists of the following parts:

- Signature® flowmeter (100 to 230 V AC). Hardware version 3.06.
- TIENet™ model 310 ultrasonic level sensor
- Teledyne sunshade with modification
- Optional external power loss alarm (required for MCERTS conformity).

This certificate applies to all instruments fitted with software version 1.21.037 onwards (Signature® flowmeter serial number 212C02317 & TIENet™ model 310 ultrasonic level sensor serial number 213B00922 onwards).







Certified Performance

The instrument was evaluated for use under the following conditions:

Ambient Temperature Range: -20°C to +60°C Instrument IP rating: NEMA 4X/IP66

The instrument meets MCERTS Class 3 requirements for the combined performance characteristic as specified in Table 7 of the MCERTS performance standard. Details of individual performance characteristics are summarised below:

Results are expressed as error % certification range 0.003 to 3m, unless otherwise stated.

Test	Results expressed as % of the certification range				Other results	MCERTS specification
	<0.5	<1	<2	<5		-
Protection against unauthorised access			Clause 3.1.2			
Indicating device	The flo	wmeter o	Clause 3.1.3			
Units of measurement		Clause 3.1.7				
Combined performance characteristic					Note 1	Class 3
					0.67	Table 7
Mean error	0.48					Clause 6.3.2 <±1% Class 3
Repeatability						Clause 6.3.2
	0.03					<±0.1% Class 1
Supply voltage						Clause 6.3.3
100 to 240 V AC	0.04					<±0.075% Class 2
Output impedance					Note 2	Clause 6.3.4
	<0.01					<±0.025% Class 1
Ambient air temperature						Clause 6.3.6
	0.1					<±0.25% Class 3
Relative humidity					Note 3	Clause 6.3.6
		0.64				<±0.25% Class 3
Direct solar radiation				_		Clause 6.3.10
	0.23					<±0.5% Class 3







Test	Results expressed as error % reading				Other results	MCERTS specification
	<0.5	<1	<2	<5		
Accuracy of computation					Note 2	Clause 6.3.11
	-0.2					<±0.25%
	-0.2					Class 3
User defined stage-discharge equation					Note 2	Clause 6.3.12
	0.09					<±0.25%
	0.09					Class 3
Resolution						Clause 3.1.15
					1mm	Class 1
Response time						Clause 6.3.19
					14 secs	< 30 secs
Error under field test conditions						Clause 7.3
	Max error		0.47%			0.5% Class 2
	Min err	or	0.00%			
	Mean error 0.04%					
	Prop		errors ≤0. 5%	2% =		
	Prop	ortion of o	errors ≤0. 0%	5% =		
Up time						Clause 7.4
					100%	>95%
Maintenance					30 mins	Clause 7.5
					scheduled during field trial	To be reported

- Note 1: The combined performance characteristic reported is the root-sum-square addition of the maximum errors recorded in the following tests: mean error, repeatability, supply voltage, output impedance, ambient air temperature, direct solar radiation, computational accuracy and resolution.
- Note 2: A simulated level input using a Teledyne ISCO TIENet™ 310 ultrasonic level sensor was used to evaluate the software / electronics response of the Signature unit.
- Note 3: Result does not meet the specification for MCERTS Class 3 at 95% RH condensing.







Description

The Signature® Flow Meter is designed for open channel flow monitoring applications using any combination of flow and parameter measurement technologies and sampling, depending on what is required at the measurement site.

The ultrasonic level sensor can be used in almost any open channel flow application and performance is unaffected by conditions that affect in situ sensors mounted in the water. The sensor is mounted above the flow stream at the appropriate measuring point in the weir, flume, or other open channel flow situation. The depth measurement is derived by measuring the distance between sensor and surface of the liquid level in the flow stream.

The Signature Flow Meter can calculate flow using standard open channel level-to-flow conversions, as well as user-defined equations, level to area data points or level to flow data points, depending upon the measurement device(s) used in the application and the program specified by the user.

The Signature Flow Meter allows multiple simultaneous flow technologies, input for pH and temperature, accepts input from SDI-12 devices and Modbus devices, provides multiple analogue output signals, and includes other interface options. The Signature has a graphical display for viewing of parameter measurements and instrument configuration. It is compatible with Teledyne Isco Flowlink software which allows on site or remote data collection or instrument configuration. The Signature has a front panel notification LED to indicate an alarm condition. The Signature is capable of communicating through an Ethernet modem, a cellular modem, or an USB interface.

The Signature flow meter has features to verify data integrity. It logs events such as changes in calibration and power outages to validate data accuracy. Data can be reviewed to detect any type of data alteration. Program reports, summary reports, and time series data are retrievable using a USB flash drive.

With multiple smart interface options and multi-parameter logging (such as pH), the Signature Flow Meter provides a common platform for control action, reporting, and communication.







General Notes

- 1. This certificate is based upon the equipment tested. The Manufacturer is responsible for ensuring that on-going production complies with the standard(s) and performance criteria defined in this Certificate. The Manufacturer is required to maintain an approved quality management system controlling the manufacture of the certified product. Both the product and the quality management system shall be subject to regular surveillance according to 'Regulations Applicable to the Holders of Sira Certificates'. The design of the product certified is defined in the Sira Design Schedule for certificate No. Sira MC140261/00
- 2. If certified product is found not to comply, Sira Certification Service should be notified immediately at the address shown on this certificate.
- 3. The Certification Marks that can be applied to the product or used in publicity material are defined in 'Regulations Applicable to the Holders of Sira Certificates'.
- 4. This document remains the property of Sira and shall be returned when requested by the company.