Teledyne Isco 2160 LaserFlowTM Module

The 2160 LaserFlow[™] Module uses non-contact Laser Doppler Velocity technology and non-contact Ultrasonic Level technology to remotely measure open channel flow. The sensor has advanced technology to measure velocity with a laser beam at single or multiple points below the surface of the wastewater stream.

The LaserFlow is ideal for a broad range of wastewater monitoring applications.

During submerged conditions, flow measurement continues without interruption with optional Doppler Ultrasonic Area Velocity technology.

In field use, the 2160 is typically powered either by two alkaline, or Isco Rechargeable Lead-acid batteries, within a 2191 Battery Module. Other power options (including solar) are available.

Applications

- Permanent and portable flow measurement for CSO, SSO, I&I, SSEs, CMOM, and other sewer monitoring programs
- Shallow flow measurement in varying pipe sizes
- Wastewater treatment plant influent, process, and effluent flow measurement
- Stormwater conveyance and outfall
- Irrigation canals and channels



The LaserFlow™ velocity sensor transmits level and velocity data back to the 2160 module.



Standard Features

- Rugged, submersible enclosure fulfills IP68 enclosure requirements
- The quick-connect sensor can be easily removed and interchanged in the field without requiring recalibration
- Up to four 2100 Series flow modules can be networked by stacking and/or extension cables
- Modbus output interface

Options and Accessories

- Flow measurement during submerged conditions via Ultrasonic Doppler technology
- Redundant flow measurement w/ simultaneous Continuous Wave Doppler and/or Ultrasonic Level Sensing
- Remote cell phone communication options
- Analog output module

Flowlink® Data Analysis

Isco Flowlink® Software is a powerful tool for analyzing flow and water quality data. It provides site setup, data retrieval, and comprehensive data analysis, as well as advanced reporting and graphing. See separate data sheets for details on Flowlink and Flowlink Pro software.

Specifications – 2160 LaserFlow™ Module		
Size (H×W×D)		2.9 × 11.3 × 7.5 in. 7.4 × 28.7 × 19.1 cm
Weight Alone Weight w/ 2191 Battery Module		2.0 lbs 0.9 kg 6.0 lbs 2.7 kg
Material		High-impact polystyrene, Stainless steel
Enclosure (self-certified)		IP 68
Power		7.0 to 16.6 VDC, Typical operating current 25 mA at 12 VDC Nominal, 1.0mA standby.
Typical Battery Life ^a (2160 mod- ule w/ 2191 Battery Module & LaserFlow Sensor)		Data Storage Interval Alkaline Batteries ^a 15 minutes 12 weeks
Program Memory		Non-volatile, programmable flash; can be updated using PC without opening enclosure; retains user program after updating
Number of Modules		Up to 4, field interchangeable
Maximum Distance between Remote Modules		3300 ft 1000 m
Wiring between Modules		Twisted pair for communication, pair for power, gauge dependent on distance
Total Flow Calculations		Up to 2 independent level-to-area and/or level-to-flow rate conversions, net, positive or negative, based on either flow rate conversion
Level-to-Area Conversions		
Channel Shapes		Round, U-shaped, rectangular, trapezoidal, elliptical, with silt correction
Data Points		Up to 50 level-area pairs
Level-to-Flow Rate Conversions		
Weirs		V-notch, rectangular, Cipolletti, Isco Flow Metering Inserts, Thel-Mar
Flumes		Parshall, Palmer-Bowlus, Leopold-Lagco, trapezoidal, H, HS, HL
Manning Formula		Round, U-shaped, rectangular, trapezoidal
Data Points		Up to 50 level-flow rate pairs
Equation		2-term polynomial
Data Storage Memory		Non-volatile flash; retains stored data during program updates
Capacity		798,000 bytes (up to 158,000 readings, equal to over 270 days of level, velocity, flow rate, ultrasonic signal, Doppler frequency, and input voltage readings at 15 minute intervals).
Data Types		Combined Flow, Flow Rate, Flow Rate 2, Total Flow, Input Voltage LaserFlow: Level, Distance, Velocity, Case Temperature, Laser Temperature, X-Axis, Y-Axis, Laser Diode Current, Ultrasonic Signal, Sense Voltage, Air Temperature, Doppler Power, Window Temperature Optional 350 AV Sensor: Level, Temperature, Velocity, Signal, Spectrum, Spectrum Ratio
Storage Mode		Rollover with variable rate data storage
Storage Interval		15 or 30 seconds; 1, 2, 5, 15, or 30 minutes; or 1, 2, 4, 12, or 24 hours
Bytes per re		5
Setup and Data Retrieval		Serial connection to IBM PC or compatible computer with Isco Flowlink software
Baud Rate		38,400
Temperature range		-40° to 140°F -40° to 60°C Operating and Storage
romportunity ramige		2 12 12 12 12 12 14 15 15 15 15 15 15 15 15 15 15 15 15 15

a. Specification for Eveready Energizer® alkaline lantern batteries, model #529, Isco part #340-2006-02. Eveready Energizer® is a registered trademark of Union Carbide Corporation.



TELEDYNE ISCO 4700 Superior Street USA and Canada (80 Everywhereyoulook Lincoln, NE 68504 USA Fax: (402) 465-3022 4700 Superior Street USA and Canada (800) 228-4373

Tel: (402) 464-0231 E-Mail: IscoInfo@teledyne.com

Teledyne Isco reserves the right to change specifications without notice. ©2012 Teledyne Isco L-2155 05/14

